

BELAR ORDERING INFORMATION

END USER INFORMATION (CALL LETTERS, COMPANY, Etc. & LOCATION) IS REQUIRED WITH ALL ORDERS

Please Contact Arno Meyer with any questions.

FMMA-1 Wizard

ORDER OPTION 01, When source of wideband composite, such as that from a monitor, is not available.

- **ORDER OPTION 02** (Down Converter/AM Noise and AM Synchronous Noise detector), For use at transmitter. **DC-4** Frequency Agile Down Converter may be substituted for OPTION 02 when frequency agility is required..
- **ORDER RFA-4** RF Amplifier, For use at studio or other off-air application.

Note that the FMSA-1 is required for stereo decoding and measurements in either case.

AMMA-2 Wizard

AMMA-2 Comes complete with Demod. Standard input impedance is 500Ω—if 50Ω input impedance is needed, specify when ordering. The **MP-17** Analog Meter Panel, is available, for full-time analog display of positive, negative modulation and carrier level.

The following equipment requires you to Specify Carrier Frequency, Channel or Visual & Aural Frequency.

FMM-2

RFA-1A

FMRR-1A

TVM-100

RFA-2 (also used with what Belar monitor? Used with LP-1A Loop Antenna?)

AMM-4 (If not U.S., we need carrier frequency, or specify 1 kHz or 10 kHz spacing.)

TVM-101

TVM-101E

TVM-102

TVM-2A

TVM-3A

RFA-3

LP-1

LP-1A (source of power, RFA-2 or power supply?)

If the following equipment is ordered separately, what will it be used with?

FMSA-1

PWM-1 (Serial # of FMM-2)

SCM-2 (We recommend the SCMA-1) Any frequencies in addition to the standard 67 kHz?

FMS-2

RFA-4

The following equipment has no special requirements.

AMM-2C

AMM-3A

AMDA-1

AS-1

FMRR-4

RDS-1

CSA-1

DC-4

DSD-1

DSD-1A

FMM-4A

SCMA-1

TVMA-1

TVM-230

TVM-250

ALL Meter Panels

FOR INTERNATIONAL ORDERS: In addition to the above information, we need de-emphasis (where applicable) and line voltage.



BELAR ELECTRONICS LABORATORY, INC.

119 LANCASTER AVE., P.O. BOX 76, DEVON, PA 19333-0076

Voice (610) 687-5550 • Fax (610) 687-2686

WEB: <http://www.belar.com> • Email: sales@belar.com, service@belar.com, parts@belar.com

Where Accuracy Counts...Count on Belar